

Technical
Data Sheet



Willamette Valley Company

www.wilvaco.com

800.333.9826

Partnering through service,
innovation, and integrity

POLYQuik® FASTPATCH NS

Vertical repair product for concrete

DESCRIPTION

FastPatch NS is a rigid two-component product designed to repair concrete. It is a non-sag, trowelable, solventless product that is mechanically mixed and hand applied. FastPatch NS has excellent adhesion to concrete and can be sanded to match the elevation of the surrounding repair area.

WHERE TO USE

- **Walls**—fill voids or patch defects
- **Pillars**—repair damaged areas
- **Sidewalks**—transitions or spalls
- **Curbs**—broken or damaged areas

FEATURES AND BENEFITS

- **Non-Sag**—ideal for vertical repairs
- **Trowelable**—easy to apply
- **Excellent Adhesion**—restore damaged areas
- **Durable**—absorbs impacts and stress

PACKAGING

- 2-gallon kit
- 5-gallon kit

COLORS

Gray

YIELD

- 2-gallon kit = 1 gal resin mixed (0.13ft³)
- 5-gallon kit = 2 gal resin mixed (0.27ft³)

SHELF LIFE

1 year when properly stored.

STORAGE

Store and ship this product in a clean, dry, low-humidity, shaded or covered environment at 60 to 90° F (15 to 32° C).

TECHNICAL INFORMATION

Typical Properties

VOC , lbs/gal (g/L), ASTM D 2369	0
Viscosity , cps, ASTM D 4878, mixed	20,000
Service temperature , ° F (° C)	-40 to 180 (-40 to 82)
Potlife , min., 70° F (21° C)	20
Tack-free time , min., 70° F (21° C)	180
Return to service , (hr) 70° F (21° C)	4 – 6
Hardness , Shore D, ASTM D 2240	70
Concrete adhesion , psi (MPa), ASTM D 4541	500 (3.4) 100% substrate
Compressive Strength , psi, ASTM D 695	4,050

Processing Parameters

Ratio by volume	2 to 1 (Resin to Iso)
Application temp , ° F (° C)	50 to 90 (10 to 32)
Recommended thickness inches (mm)	0.25 to 4 (6.4 to 100)

APPLICATION

SURFACE PREPARATION CONCRETE

1. The concrete surface being repaired must be fully cured 28 days, structurally sound (200psi or greater according to ASTM D7234), clean (ASTM D4258), and dry (less than 5%, ASTM E1907).
2. Concrete surface must be dry and clean. Water or oil present can result in poor adhesion. Apply product only if surface temperature is 5° F (3° C) above the dew point to avoid application over damp surface.
3. Remove any contaminants before profiling surface.
4. It is recommended to profile surface according to ICRI Guide 03732 to a minimum of CSP 3 by abrasive blasting.
5. Saw cut spall area in shape of a square 1-3 inches (2.54-7.6 cm) deep, hammer (15 lb) spall area and remove debris. Recommended repair size is less than 10 ft² (1m²).
6. Use a minimum 150 PSI continuously dry compressed air to blow out loose debris, dirt and dust prior to applying product. Moist concrete can be torched dry. If moisture returns immediately after torching, stop and do not install FASTPATCH in this area.
7. Use a steel bristle brush to remove dirt on vertical and horizontal concrete surfaces and use compressed air to blow out prior to applying product.
8. As necessary, plug all gaps or joints surrounding the spall area with foam backer rod and choose a rod width that fits tightly in the area.
9. Priming all concrete surfaces is recommended. Prime with POLYPrime or contact WVCO for proper primer selection. Refer to primer TDS sheets for detailed instructions
10. For spall areas, honor all joints or moving cracks in the spall area by saw-cutting after FASTPATCH has cured.

OTHER MATERIALS

1. Previously installed polymer materials must be tested to determine the best method of preparation to achieve acceptable adhesion. Consult manufacturer for recommendations. Typically, methods will include solvent cleaning, abrading, and vacuuming surface.
2. FASTPATCH is not typically recommended for use in asphaltic roadways. Exceptions do occur; contact Willamette Valley Co. for more details.
3. Do NOT place FASTPATCH on asphaltic materials, bare ground, dirt, grass or other non-structure surfaces.

PROCESSING

1. Precondition the containers to 70°F (21°C) for 24 hours before using.

2. The materials are supplied in ready-to-combine kits. USE THE ENTIRE KIT AND DO NOT DIVIDE. ONLY use WVCO approved sand as filler.
3. Check that primed surfaces are ready for application of FASTPATCH before applying mixed material.
4. Ensure that the mixing station is a short distance from the application area. Multiple kits can be mixed at the same time when repairing large or multiple repairs.
5. Use entire kit and do not divide.
6. Attach a clean mixing blade with a width approximately 1/3 the diameter of the mixing container to a 500RPM drill.
7. POTLIFE IS LESS THAN 20 MINUTES. Material will continue to thicken after initial mix. Wait for 10 minutes after initial mix if greater non-sag properties are required.

APPLICATION

1. Protect the surfaces around the application area to prevent contamination during the installation.
2. Remove the two containers from the kit while leaving the sand. Shake the resin container for 30 seconds and pour the contents into the mixing bucket with the sand.
3. Mix the resin and sand together for 30 seconds or until the sand is completely wetted out by the resin.
4. Add the iso to the bucket and mix for 40 seconds. Scrape the SIDES and BOTTOM of the bucket with a wooden straight edge and continue to mix for an additional 40 seconds. All of the iso must be thoroughly incorporated in the resin before adding it to the defect. THE MATERIAL WILL NOT SET-UP IF IT IS IMPROPERLY MIXED. Signs of poor mixing include dark swirls and tacky material that does not solidify.
5. Use a plastic trowel to level FASTPATCH. Do not overwork material and avoid feathering material. Thin areas less than 1/4 " (6.4 mm) may bubble. Sand or grind to remove any bubbled areas.
6. Add the topping sand as necessary when the material has gelled. Add topping sand to refusal.

CLEANING & MAINTENANCE

- Use Acetone or POLYQuik® Cleaner to clean mixing blade and other equipment. Cured material must be removed mechanically.

HEALTH AND SAFETY

Before handling, you should become familiar with the Material Safety Data Sheet (MSDS) regarding the risks and safe use of this product. To obtain an MSDS please call 800 333 9826 or send an email to: msds@wilvaco.com.

WILLAMETTE VALLEY COMPANY

www.wilvaco.com
info@wilvaco.com

DIVISIONS

WESTERN DIVISION

1075 Arrowsmith Street
PO Box 2280
Eugene, OR 97402
Tel 541.484.9621
www.POLYQUIK.com
www.SPIKEFAST.com

EASTERN DIVISION

6662 Marbut Road
Lithonia, GA 30058
Tel 888.878.9826

MIDWEST DIVISION

1549 Hwy 2
Two Harbors, MN 55616
Tel 218.834.3922

PRECISION TECHNOLOGIES DIVISION

675 McKinley Street
Eugene, OR 97402
Tel 541.484.2368
www.pre-tec.com

SOUTHERN DIVISION

100 Dixie Mae Drive
PO Box 4450
Pineville, Louisiana 71361
Tel 318.640.5077

SUBSIDIARIES

CANADIAN WILLAMETTE

19081- 27th Avenue
Surrey BC V3S 5T1
Tel. 800.663.4298

ECLECTIC PRODUCTS INC.

Corporate Office
1075 Arrowsmith Street
Eugene, OR 97402
Tel 541.284.4667
www.eclecticproducts.com

IDAHO MILL & GRAIN

445 North 430 West Hwy
Po Box 188
Malad City, Idaho 83252
Tel 208.766.2206

TAPEL WILLAMETTE LTD. S.A.

Av. Estero La Posada 3625 Parque
Industrial Coronel Coronel, Chile
Tel 011.56.41.928.100
www.tapel.cl

DISCLAIMER OF WARRANTY

TEST RESULTS ARE TO BE CONSIDERED AS REPRESENTATIVE OF CURRENT PRODUCTION AND SHOULD NOT BE TREATED AS SPECIFICATIONS. WHILE ALL THE INFORMATION PRESENTED IN THIS DOCUMENT IS BELIEVED TO BE RELIABLE AND TO REPRESENT THE BEST AVAILABLE DATA ON THESE PRODUCTS, NO GUARANTEE, WARRANTY, OR REPRESENTATION IS MADE, INTENDED, OR IMPLIED AS TO THE CORRECTNESS OR SUFFICIENCY OF ANY INFORMATION, OR AS TO THE SUITABILITY OF ANY CHEMICAL COMPOUNDS FOR ANY PARTICULAR USE, OR THAT ANY CHEMICAL COMPOUNDS OR USE THEREOF ARE NOT SUBJECT TO A CLAIM BY A THIRD PARTY FOR INFRINGEMENT OF ANY PATENT OR OTHER INTELLECTUAL PROPERTY RIGHT. EACH USER SHOULD CONDUCT A SUFFICIENT INVESTIGATION TO ESTABLISH THE SUITABILITY OF ANY PRODUCT FOR ITS INTENDED USE.

PROPER APPLICATION IS THE RESPONSIBILITY OF THE USER. AS WITH ANY PRODUCT THE USE OF THIS PRODUCT IN A GIVEN APPLICATION MUST BE TESTED (INCLUDING BUT NOT LIMITED TO FIELD TESTING) IN ADVANCE BY THE USER TO DETERMINE SUITABILITY. TESTING IS THE REQUIREMENT OF BOTH ENGINEERS AND CONTRACTORS ALIKE. WVCO DOES NOT WARRANT THE APPLICATION UNDER ANY OR ALL CIRCUMSTANCES.



Revision Date: September 2012